



EPLC9600-PID QUADRO 96 x 96 DIN 1/4 4 Channel PID Controller

- 128 x 64 Graphical LCD display
- 4 Thermocouple (J, K, L, R or S type) sensor inputs
- Configurable P, PI, PD and PID control forms
- Auto-Tuning and Self-Tuning (automatic calculations of PID parameters)
- Relay or (pnp "source") transistor outputs
- Sensor error detection
- Programmable heating and cooling for PID control outputs
- Soft-Start (Ramp action during power on) specification
- ECO and SLEEP mode selection
(mode can be activating automatically according to mode control parameter which can be adjust for each day of week or via front panel buttons or via digital inputs.)
- Adjustable temperature offset for each channel
- 3 Different alarm types for each channel
(High, Low and Band Alarms)
- User defined channel labels
- Operating with Real Time Clock (RTC)
- ModBus RTU communication protocol
(RS-232, RS-485 and Ethernet communication)
- Data Logging to USB Flash Memory
- Adjustable data logging time interval
- Password protection for programming mode

ABOUT INSTRUCTION MANUAL

Instruction manual of EPLC9600-PID QUADRO consists of two main sections. Explanation of these sections are below. Also, there are other sections which include order information and technical specifications of the device. All titles and page numbers in instruction manual are in “**CONTENTS**” section. User can reach to any title with section number.

Installation:

In this section, physical dimensions of the device, panel mounting, electrical wiring, physical and electrical installation of the device to the system are explained.

Operation and Parameters:

In this section user interface of the device, accessing to the parameters, description of the parameters are explained.

Also in these sections, there are warnings to prevent serious injury while doing the physical and electrical mounting or using the device.

Explanation of the symbols which are used in these sections are given below.



This symbol is used for safety warnings. User must pay attention to these warnings.



This symbol is used to determine the dangerous situations as a result of an electric shock. User must pay attention to these warnings definitely.



This symbol is used to determine the important notes about functions and usage of the device.

CONTENTS

| | | |
|---|------|----|
| 1.PREFACE | Page | 5 |
| 1.1 GENERAL SPECIFICATIONS | | |
| 1.2 ORDERING INFORMATION | | |
| 1.3 WARRANTY | | |
| 1.4 MAINTENANCE | | |
| 2.INSTALLATION | Page | 7 |
| 2.1 GENERAL DESCRIPTION | | |
| 2.2 FRONT VIEW AND DIMENSIONS OF EPLC9600-PID QUADRO | | |
| 2.3 PANEL CUT-OUT | | |
| 2.4 ENVIRONMENTAL RATINGS | | |
| 2.5 PANEL MOUNTING | | |
| 2.6 INSTALLATION FIXING CLAMP | | |
| 2.7 REMOVING FROM THE PANEL | | |
| 3.ELECTRICAL WIRING | Page | 12 |
| 3.1 TERMINAL LAYOUT AND CONNECTION INSTRUCTIONS | | |
| 3.2 ELECTRICAL WIRING DIAGRAM | | |
| 3.3 SUPPLY VOLTAGE INPUT CONNECTION OF THE DEVICE | | |
| 3.4. GALVANIC ISOLATION TEST VALUE OF EPLC9600-PID QUADRO | | |
| 4. CABLE CONNECTION BETWEEN RS232 TERMINAL OF THE DEVICE AND PC | Page | 16 |
| 5. CONNECTION FOR RS485 SERIAL COMMUNICATION | Page | 17 |
| 6. DEFINITION OF THE FRONT PANEL AND ACCESSING TO THE PARAMETERS | Page | 18 |
| 6.1 DEFINITION OF FRONT PANEL | | |
| 6.2 MAIN OPERATION SCREEN DEFINITION | | |
| 6.3 ACCESSING TO THE OPERATOR PARAMETER PAGES | | |
| 6.4 ACCESSING TO THE TECHNICIAN PARAMETER PAGES | | |
| 6.5 ACCESSING TO THE CALIBRATION PARAMETER PAGES | | |
| 6.6 OPERATOR PAGES PARAMETERS DEFINITIONS | | |
| 6.7 TECHNICIAN PAGES PARAMETERS DEFINITIONS | | |
| 6.7.1 PAGE-1 PARAMETERS | | |
| 6.7.2 PAGE-2 PARAMETERS | | |
| 6.7.3 PAGE-3 PARAMETERS | | |
| 6.7.4 PAGE-4 PARAMETERS | | |
| 6.7.5 PAGE-5 "ECO MODE" PARAMETERS | | |
| 6.7.6 PAGE-6 "SLEEP MODE" PARAMETERS | | |
| 6.7.7 PAGE-7 "RS232" PARAMETERS | | |
| 6.7.8 PAGE-8 "RS485" PARAMETERS | | |
| 6.7.9 PAGE-9 "USB" PARAMETERS | | |
| 6.7.10 PAGE-10 "ETHERNET" PARAMETERS | | |
| 6.7.11 PAGE-11 "REAL TIME (RTC)" PARAMETERS | | |
| 7.OPERATION GRAPHICS OF ALARM TYPE | Page | 43 |
| 8.MODBUS ADDRESS | Page | 44 |
| 8.1 PID CONTROL AND ALARM OUTPUT MODBUS ADDRESSES | | |
| 8.2 PROCESS INPUT VALUES MODBUS ADDRESSES | | |
| 9.SPECIFICATIONS | Page | 45 |
| 10.OTHER INFORMATIONS | Page | 45 |

EU DECLARATION OF CONFORMITY

Manufacturer's Name : EMKO ELEKTRONIK A.S.
Manufacturer's Address : DOSAB, Karanfil Sk., No:6,
16369 Bursa, TURKEY

The manufacturer hereby declares that the product:

Product Name : PID QUADRO (4 Channel PID Controller)
Type Number : EPLC9600
Product Category : Electrical equipment for measurement, control and laboratory use

Conforms to the following directives :

2006 / 95 / EC The Low Voltage Directive

2004 / 108 / EC The Electromagnetic Compatibility Directive

has been designed and manufactured to the following specifications:

EN 61000-6-4:2007 EMC Generic Emission Standard for Industrial Environments

EN 61000-6-2:2005 EMC Generic Immunity Standard for Industrial Environments

EN 61010-1:2001 Safety Requirements for electrical equipment for measurement, control and laboratory use

When and Where Issued

04th August 2011

Bursa-TURKEY

Authorized Signature

Name : Serpil YAKIN

Position : Quality Manager

1.Preface

EPLC9600-PID QUADRO series 4 channel PID controller devices are designed for measuring, controlling and logging temperatures of 4 different area. They can be used in many applications with their TC process input, multifunction PID control outputs, alarm outputs, selectable alarm functions, RS-232 / RS-485 / Ethernet / USB communications.

Some application fields and applications which they are used are below:


Application Fields

Glass
 Plastic
 Petro-Chemistry
 Textile
 Automative
 Machine production industries
 etc...

Applications

Heating
 Baking Ovens
 Incubators
 Storages
 Storages
 etc..

1.1 General Specifications



1.2 Ordering Information

| | | | | | | | |
|---|---|---|---|------------------|---|---|---|
| EPLC9600-PID QUADRO (96 x 96 1/4 DIN) | | A | . | B | C | D | E |
| | | | . | R | 2 | | |
| A Supply Voltage | | | | | | | |
| 1 | 100...240V ~ (-%15;+%10) 50/60Hz | | | | | | |
| 2 | 24V~(-%15;+%10) 50/60Hz | | | 24V==(-%15;+%10) | | | |
| 9 | Customer | | | | | | |
| B Outputs | | | | | | | |
| R | 10 Relay outputs with 2 common for each NO contact 5A max. (5A@250V at resistive load) for each Common contact 15A max (15A@250V at resistive load) | | | | | | |
| C Standard Serial Communication | | | | | | | |
| 2 | RS-232 (up to 115200 baudrate, "No isolation") | | | | | | |
| D Optional Communication-1 | | | | | | | |
| 0 | None | | | | | | |
| 4 | RS-485 (up to 115200 baudrate, "500VAC isolation") | | | | | | |
| E | ETHERNET (10Mbit/s, "1500VAC isolation") | | | | | | |
| E Optional Communication-2 | | | | | | | |
| 0 | None | | | | | | |
| U | USB (USB2.0 "for temperature data logging") | | | | | | |

All order information of EPLC9600-PID QUADRO are given on the table at left. User may form appropriate device configuration from information and codes that at the table and convert it to the ordering codes.

Firstly, supply voltage then other specifications must be determined. Please fill the order code blanks according to your needs.

Please contact us, if your needs are out of the standards.

Table-1

| Input Type(TC) | Scale(°C) |
|-------------------------------|---------------|
| J, Fe CuNi IEC584.1(ITS90) | -100°C,900°C |
| K, NiCr Ni IEC584.1(ITS90) | -100°C,1300°C |
| L, Fe Const DIN43710 | -100°C,850°C |
| R, Pt13%Rh Pt IEC584.1(ITS90) | 0°C,1700°C |
| S, Pt10%Rh Pt IEC584.1(ITS90) | 0°C,1700°C |

1.3 Warranty

EMKO Elektronik warrants that the equipment delivered is free from defects in material and workmanship. This warranty is provided for a period of two years. The warranty period starts from the delivery date. This warranty is in force if duty and responsibilities which are determined in warranty document and instruction manual performs by the customer completely.

1.4 Maintenance

Repairs should only be performed by trained and specialized personnel. Cut power to the device before accessing internal parts.

Do not clean the case with hydrocarbon-based solvents (Petrol, Trichlorethylene etc.). Use of these solvents can reduce the mechanical reliability of the device. Use a cloth dampened in ethyl alcohol or water to clean the external plastic case.

2. Installation



Before beginning installation of this product, please read the instruction manual and warnings below carefully.

In package ,

- One piece unit
- Two pieces mounting clamps
- One piece instruction manual

A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.

If there is danger of serious accident resulting from a failure or defect in this unit, power off the system and separate the electrical connection of the device from the system.

The unit is normally supplied without a power supply switch or a fuse. Use power switch and fuse as required.

Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

Never attempt to disassemble, modify or repair this unit. Tampering with the unit may results in malfunction, electric shock or fire.


Do not use the unit in combustible or explosive gaseous atmospheres.

During the equipment is putted in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you must be careful.


Montage of the product on a system must be done with it's fixing clamps. Do not do the montage of the device with inappropriate fixing clamp. Be sure that device will not fall while doing the montage.

It is your responsibility if this equipment is used in a manner not specified in this instruction manual.


2.1 General Description



2.2 Front View and Dimensions of EPLC9600-PID QUADRO



2.3 Panel Cut-Out



2.4 Environmental Ratings

Operating Conditions



Operating Temperature : 0 to 50 °C



Max. Operating Humidity : 90% Rh (non-condensing)



Altitude : Up to 2000m.




Forbidden Conditions:

Corrosive atmosphere

Explosive atmosphere

Home applications (The unit is only for industrial applications)

2.5 Panel Mounting



1-Before mounting the device in your panel, make sure that the cut-out is of the right size.


2-Check front panel gasket position

3-Insert the device through the cut-out. If the mounting clamps are on the unit, put out them before inserting the unit to the panel.



During installation into a metal panel, care should be taken to avoid injury from metal burrs which might be present. The equipment can loosen from vibration and become dislodged if installation parts are not properly tightened. These precautions for the safety of the person who does the panel mounting.

2.6 Installation Fixing Clamp



The unit is designed for panel mounting.

1-Insert the unit in the panel cut-out from the front side.

2- Insert the mounting clamps to the holes that located top and bottom sides of device and screw up the fixing screws until the unit completely immobile within the panel




Montage of the unit to a system must be done with it's own fixing clamps. Do not do the montage of the device with inappropriate fixing clamps. Be sure that device will not fall while doing the montage.

2.7 Removing from the Panel



Before starting to remove the unit from panel, power off the unit and the related system.



1-Loosen the screws.

2-Pull mounting clamps from top and bottom fixing sockets.

3-Pull the unit through the front side of the panel

3. Electrical Wirings



You must ensure that the device is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct.

Device parameters has factory default values. These parameters must be set according to the system's needs.



Only qualified personnel and technicians should work on this equipment. This equipment contains internal circuits with voltage dangerous to human life. There is severe danger for human life in the case of unauthorized intervention.




Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.




Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

3.1 Terminal Layout and Connection Instructions

Terminal layout for ethernet communication




Terminal layout for RS485 communication



Max. 2.5mm / 0.098 inch
Wire Size:
18AWG/1mm²
Solid /Stranded

Torque
0,5Nm


Screw driver
0,8 x3mm



3.2 Electrical Wiring Diagram




Electrical wiring of the device must be the same as 'Electrical Wiring Diagram' below to prevent damage to the process being controlled and personnel injury.



RS485, Ethernet and USB communications are optional

3.3 Supply Voltage Input Connection of the Device



Note-1 : There is an internal 33R fusible flameproof resistor in 100-240 V \sim 50/60Hz
 There is an internal 4R7 fusible flameproof resistor in 24V \sim 50/60Hz

Note-2: “L” is (+), “N” is (-) for 24V --- Supply Voltage

Note-3: External Fuse is recommended



Make sure that the power supply voltage is same indicated on the instrument. Switch on the power supply only after that all the electrical connection have been completed.

Supply voltage range must be determined in order. While installing the unit, supply voltage range must be controlled and appropriate supply voltage must be applied to the unit. Controlling prevents damages in unit and system and possible accidents as a result of incorrect supply voltage.



There is no power supply switch or fuse on the device. So a power supply switch and a fuse must be added to the supply voltage input. Power supply switch and fuse must be put to a place where user can reach easily.

Power supply switch must be two poled for seperating phase and neutral. On/Off condition of power supply switch is very important in electrical connection. On/Off condition of power supply switch must be signed for preventing the wrong connection.


External fuse must be on phase connection in \sim supply input.

External fuse must be on (+) line connection in --- supply input.




The instrument is protected with an internal fuse (Please refer to Note-1 for information). In case of failure it is suggested to return the instrument to the manufacturer for repair.

3.4 Galvanic Isolation Test Values of EPLC9600-PID QUADRO




4. Cable Connection Between RS-232 Terminal of the Device and PC

PC (Personal Computer)
9 Pin DCON connection



5. Connection for RS-485 Serial Communication

PC(Personal Computer)



32 terminal can be connected in RS-485 line

R_t resistor = 120


For communication connection Twisted Pair cable must be used











Cable length can be maximum 1000 meters in 9600 baud rate.

When baud rate increases, cable length must be decreased.



6. Definition of the Front Panel and Accessing to the Parameters

6.1. Definition of Front Panel



-  **ENTER BUTTON**
This button is used to confirm the variable value in variable value changing screen.
-  **ESCAPE BUTTON**
This button is used to exit from variable value changing screen to preceding visualization screen without saving variable value, and return to main operation screen.
-  **DELETE BUTTON**
This button is used to delete the last digit of the value in variable value changing screen.
-  **CHANGE CASE BUTTON**
This button is used to changing the character between uppercase and lowercase, which cursor is show for string variable in variable value changing screen.
-  **SIGN & SYMBOL BUTTON**
This button is used to changing the sign value for sign type variables, entering the dot for real type and entering the symbol character for string type variables in variable value changing screen.
-  **DOWN BUTTON**
This button is used to decrement the digit, which cursor is show of variable in variable value changing screen and used to accessing next programming page in programming mode.
-  **UP BUTTON**
This button is used to increment the digit, which cursor is show of variable in variable value changing screen and used to accessing previous programming page in programming mode.
-  **RIGHT BUTTON**
This button is used to move cursor to the right side for one digit in variable value changing screen and selecting the variable for changing in programming mode.
-  **LEFT BUTTON**
This button is used to move cursor to the left side for one digit in variable value changing screen and selecting the variable for changing in programming mode.
-  **PROGRAMMING MODE ACCESSING BUTTON**
This button is used to accessing to programming mode parameters pages.


6.2. Main Operation Screens Definition



If more than one alarm messages is present, each alarm message is showing on LCD screen during 1 second.

6.3. Accessing to the Operator Parameter Pages

MAIN OPERATION SCREEN



OPERATOR PARAMETERS SECTION PASSWORD SCREEN



When programming mode access button is pressed and released before 5 seconds is expire, If operator password is different from 0, operator parameter section password screen will be observed, If operator password is 0 then operator parameter screen will be observed.


Press right or left button for selecting the password parameter.

OPERATOR PARAMETERS SECTION PASSWORD SCREEN




Press enter button for accessing to password entering screen.

OPERATOR PARAMETERS SECTION PASSWORD ENTERING SCREEN




Enter the operator parameter section password with cursor (lef, right, up and down) buttons.

OPERATOR PARAMETERS SECTION PASSWORD ENTERING SCREEN



Press enter button for accessing to the operator section parameters.

OPERATOR PARAMETER SCREEN (CHANNEL-1 PARAMETERS)




Press right or left button for selecting the parameter.



If no operation is performed for 20 seconds in operator parameters section, device turns to main operation screen automatically.

OPERATOR PARAMETER SCREEN (CHANNEL-1 PARAMETERS)




Press enter button for accessing to parameter entering screen.


PARAMETER ENTERING SCREEN



Change the parameter value with cursor (lef, right, up and down) buttons.




PARAMETER ENTERING SCREEN




Press enter button for return parameter screen with saving parameter value, press escape button for return parameter screen without saving parameter value.

OPERATOR PARAMETER SCREEN (CHANNEL-1 PARAMETERS)



Press number (1,2,3 or 4) buttons for accessing the relevant channel's parameter screen.

OPERATOR PARAMETER SCREEN (CHANNEL-2 PARAMETERS)




Other operator section parameters can be accessed with same method explained above, press escape button for return to main operation screen.



If no operation is performed for 20 seconds in operator parameters section, device turns to main operation screen automatically.

6.4. Accessing to the Technician Parameter Pages

MAIN OPERATION SCREEN



TECHNICIAN PARAMETERS SECTION PASSWORD SCREEN



When programming mode access button is pressed for 5 seconds, If technician password is different from 0, technician parameter section password screen will be observed, If technician password is 0 then technician parameter screen will be observed.

Press right or left button for selecting the password parameter.

TECHNICIAN PARAMETERS SECTION PASSWORD SCREEN



Press enter button for accessing to password entering screen.

TECHNICIAN PARAMETERS SECTION PASSWORD ENTERING SCREEN




Enter the technician parameter section password with cursor (lef, right, up and down) buttons.

TECHNICIAN PARAMETERS SECTION PASSWORD ENTERING SCREEN



Press enter button for accessing to the technician section parameters.

TECHNICIAN PARAMETER SCREEN (PAGE - 1 "CHANNEL-1 PARAMETERS")




Press number (1,2,3 or 4) buttons for accessing the relevant channel's parameter screen. Press down button for accessing to next parameter page.




If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 2 “CHANNEL-1 PARAMETERS”)**




Press number (1,2,3 or 4) buttons for accessing the relevant channel’s parameter screen. Press down button for accessing to next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 3 “CHANNEL-1 PARAMETERS”)**




Press number (1,2,3 or 4) buttons for accessing the relevant channel’s parameter screen. Press down button for accessing to next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 4)**



Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 5 “ECO MODE PAGE”)**




Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 6 “SLEEP MODE PAGE”)**



Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 7 “RS232 PAGE”)**



Press down button for accessing next parameter page, press up button for accessing previous parameter page.




If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 8 "RS485 PAGE")**




Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 9 "USB PAGE")**




Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 10 "ETHERNET PAGE")**



Press down button for accessing next parameter page, press up button for accessing previous parameter page.

**TECHNICIAN PARAMETER SCREEN
(PAGE - 11 "RTC PAGE")**




Press up button for accessing previous parameter page, press escape button for return to main operation screen.

i If the device has a optional RS485 communication then RS 485 page is observed,
 If the device has a optional USB communication then USB page is observed,
 If the device has a optional ETHERNET communication then ETHERNET page is observed.
 Otherwise these pages are not observed.

i If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.5. Accessing to the Calibration Parameter Pages

MAIN OPERATION SCREEN



When programming mode access button is pressed for 5 seconds, calibration parameter section password screen will be observed

CALIBRATION PARAMETERS SECTION PASSWORD SCREEN




Press right or left button for selecting the password parameter.

CALIBRATION PARAMETERS SECTION PASSWORD SCREEN



Press enter button for accessing to password entering screen.

CALIBRATION PARAMETERS SECTION PASSWORD ENTERING SCREEN




Enter the calibration parameter section password as a 9111 with cursor (left, right, up and down) buttons.

CALIBRATION PARAMETERS SECTION PASSWORD ENTERING SCREEN



Press enter button for accessing to the calibration section parameters.

CALIBRATION PARAMETER SCREEN ("CHANNEL-1 SENSOR TYPE SELECTION")




Press number (1,2,3 or 4) buttons for accessing the relevant channel's parameter screen. Press escape button for return to main operation screen.



If no operation is performed for 20 seconds in calibration parameters section, device turns to main operation screen automatically.

6.6. Operator Pages Parameters Definitions



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|---------------|-------------------------------|------|---------|---------|---------|---------|
| PROCESS SET | PID Set Value For Channel-X | °C | SET MIN | SET MAX | 100.0 | - |
| ALARM SET | Alarm Set Value For Channel-X | °C | -100.0 | 1700.0 | 90.0 | - |
| LCD BACKLIGHT | LCD Display Backlight Mode | - | 0 | 2 | 1 | 42182 |
| LCD CONTRAST | LCD Display Contrast Value | - | 30 | 60 | 45 | 42183 |

PROCESS SET

PID set value for selected channel is can be adjusted according to this parameter.

ALARM SET

Alarm set value for selected channel is can be adjusted according to this parameter.

LCD BACKLIGHT

Display backlight is can be controlled by this parameter value. If parameter value;

0 = LCD backlight is continuously OFF

1 = LCD backlight is continuously ON

2 = "power safe mode" If any button is not pressed during 30 secs. LCD backlight is automatically changed OFF mode, when any button is pressed LCD backlight is changed ON mode again.

LCD CONTRAST

Display contrast value is can be controlled by this parameter value.

REVISION NUMBER "Software Revision Number"

Device software revision number is can be seen by this parameter.

This parameter is can not be changed, it's only observed.

Process Set Parameters Modbus Addresses

| Parameter | Address |
|---------------------------|---------|
| CHANNEL-1 PROCESS SET (*) | 42030 |
| CHANNEL-2 PROCESS SET (*) | 42042 |
| CHANNEL-3 PROCESS SET (*) | 42054 |
| CHANNEL-4 PROCESS SET (*) | 42066 |

Alarm Set Parameters Modbus Addresseses

| Parameter | Address |
|-------------------------|---------|
| CHANNEL-1 ALARM SET (*) | 42078 |
| CHANNEL-2 ALARM SET (*) | 42082 |
| CHANNEL-3 ALARM SET (*) | 42086 |
| CHANNEL-4 ALARM SET (*) | 42090 |



(*) These parameters are displayed on LCD screen with point, so that the parameters values are 10 times than the real values for modbus function.




Channel number is can be seen upper left side of the display and can be selected by pressing the channel selection buttons (1, 2, 3 or 4).



If no operation is performed for 20 seconds in operator parameters section, device turns to main operation screen automatically.

6.7. Technician Pages Parameters Definitions

6.7.1. Page-1 Parameters



| Parameter | Explanation | Unit | Min. | Max. | Default |
|--------------|--|------|------|--------|---------|
| PROPORTIONAL | PID Proportional Parameter For Channel-X | % | 1 | 100.0 | 1.0 |
| INTEGRAL | PID Integral Parameter For Channel-X | sec. | 0 | 3200.0 | 10.0 |
| DERIVATIVE | PID Derivative Parameter For Channel-X | sec. | 0 | 999.9 | 10.0 |
| OUT PERIOD | PID Ouput Period | sec. | 1 | 150 | 1 |
| OUT MINIMUM | PID Minimum Control Output | % | 0 | 100 | 0 |
| OUT MAXIMUM | PID Maximum Control Output | % | 0 | 100 | 100 |

PROPORTIONAL

PID proportional value for selected channel is can be adjusted according to this parameter. This parameter's unit is percentage of analogue input scale. If analogue input is selected as a J type TC, then analogue input scale is being between -100.0°C to 900.0°C , and if PROPORTIONAL parameter value is selected as a %10.0 then PID Proportional band is calculated like below.

$$\text{Proportional Band} = ((900.0^{\circ}\text{C} - (-100.0^{\circ}\text{C})) * 10.0) / 100 = 100^{\circ}\text{C}$$

INTEGRAL

PID integral value for selected channel is can be adjusted according to this parameter. It can be changed by the user. When tune operation stops, it can be changed by the device. If it is 0, integral control part does not run. When tune operation stops if this parameter is 0, this parameter can not be changed because of integral control part does not run.

DERIVATIVE

PID derivative value for selected channel is can be adjusted according to this parameter. It can be changed by the user. When tune operation stops, it can be changed by the device. If it is 0, derivative control part does not run. When tune operation stops if this parameter is 0, this parameter can not be changed because of derivative control part does not run.

OUT PERIOD


PID output period value for selected channel is can be adjusted according to this parameter.


OUT MINIMUM

PID minimum output value for selected channel is can be adjusted according to this parameter. Even as a result of the PID calculation device calculates the % output value less than this parameter, PID output is active minimum for this parameter.

OUT MAXIMUM

PID maximum output value for selected channel is can be adjusted according to this parameter. Even as a result of the PID calculation device calculates the % output value greater than this parameter, PID output is active maximum for this parameter.

 Channel number is can be seen upper left side of the display and can be selected by pressing the channel selection buttons (1, 2, 3 or 4).

 If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

**PID Proportional Parameters
Modbus Addresses**

| Parameter | Address |
|----------------------------|---------|
| CHANNEL-1 PROPORTIONAL (*) | 42031 |
| CHANNEL-2 PROPORTIONAL (*) | 42043 |
| CHANNEL-3 PROPORTIONAL (*) | 42055 |
| CHANNEL-4 PROPORTIONAL (*) | 42067 |

**PID Out Period Parameters
Modbus Addresses**

| Parameter | Address |
|----------------------|---------|
| CHANNEL-1 OUT PERIOD | 42040 |
| CHANNEL-2 OUT PERIOD | 42052 |
| CHANNEL-3 OUT PERIOD | 42064 |
| CHANNEL-4 OUT PERIOD | 42076 |

**PID Integral Parameters
Modbus Addresses**

| Parameter | Address |
|------------------------|---------|
| CHANNEL-1 INTEGRAL (*) | 42032 |
| CHANNEL-2 INTEGRAL (*) | 42044 |
| CHANNEL-3 INTEGRAL (*) | 42056 |
| CHANNEL-4 INTEGRAL (*) | 42068 |

**PID Out Minimum Parameters
Modbus Addresses**

| Parameter | Address |
|-----------------------|---------|
| CHANNEL-1 OUT MINIMUM | 42037 |
| CHANNEL-2 OUT MINIMUM | 42049 |
| CHANNEL-3 OUT MINIMUM | 42061 |
| CHANNEL-4 OUT MINIMUM | 42073 |

**PID Derivative Parameters
Modbus Addresses**

| Parameter | Address |
|--------------------------|---------|
| CHANNEL-1 DERIVATIVE (*) | 42033 |
| CHANNEL-2 DERIVATIVE (*) | 42045 |
| CHANNEL-3 DERIVATIVE (*) | 42057 |
| CHANNEL-4 DERIVATIVE (*) | 42069 |

**PID Out Maximum Parameters
Modbus Addresses**

| Parameter | Address |
|-----------------------|---------|
| CHANNEL-1 OUT MAXIMUM | 42038 |
| CHANNEL-2 OUT MAXIMUM | 42050 |
| CHANNEL-3 OUT MAXIMUM | 42062 |
| CHANNEL-4 OUT MAXIMUM | 42074 |




(*) These parameters are displayed on LCD screen with point, so that the parameters values are 10 times than the real values for modbus function.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.2. Page-2 Parameters



| Parameter | Explanation | Unit | Min. | Max. | Default |
|----------------|--|------|--------|--------|---------|
| SAMPLE TIME | PID Sample Time For Channel-X | sec. | 1.4 | 60.0 | 1.4 |
| SET MINIMUM | PID Minimum Set Value For Channel-X | °C | -100.0 | 1700.0 | 0.0 |
| SET MAXIMUM | PID Maximum Set Value For Channel-X | °C | -100.0 | 1700.0 | 400.0 |
| TUNE (1.A/2.S) | PID Tune Selection For Channel-X | - | 0 | 2 | 0 |
| SOFT START | PID Ouput Power On Ramp Time For Channel-X | min. | 0 | 600 | 0 |
| ALARM TYPE | Alarm Type Selection | - | 0 | 3 | 0 |

SAMPLE TIME

PID output calculation period for selected channel is can be adjusted according to this parameter.

SET MINIMUM

PID minimum set value for selected channel is can be adjusted according to this parameter.

SET MAXIMUM

PID maximum Set value for selected channel is can be adjusted according to this parameter.

TUNE (1.A/2.S)

Tune selection for selected channel is can be adjusted according to this parameter.

After tune operation is finished without any problem, device saves new PID parameters to memory and the tune parameter value is being changed to 0 automatically. If parameter value,

0 = Tune off

1 = Auto tune (Limit Cycle Tuning) operation

2 = Self tune (Step Response Tuning) operation

SOFT START

PID output for selected channel is reaches to the %output value that is measured when power first applied to the device at the end of the this parameter time. If parameter value is adjusted to 0 value or If there is a sensor break failure, then Soft-Start operation is canceled.

ALARM TYPE

Alarm type for selected channel is can be adjusted according to this parameter. If parameter value,

0 = Alarm Off,

1 = Low Alarm,

2 = High Alarm,

3 = Band Alarm is selected.



Channel number is can be seen upper left side of the display and can be selected by pressing the channel selection buttons (1, 2, 3 or 4).



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

**PID Sample Time Parameters
Modbus Addresses**

| Parameter | | Address |
|-----------------------|-----|---------|
| CHANNEL-1 SAMPLE TIME | (*) | 42034 |
| CHANNEL-2 SAMPLE TIME | (*) | 42046 |
| CHANNEL-3 SAMPLE TIME | (*) | 42058 |
| CHANNEL-4 SAMPLE TIME | (*) | 42070 |

**PID Tune Selection Parameters
Modbus Addresses**

| Parametre | | Address |
|--------------------------|--|---------|
| CHANNEL-1 TUNE (1.A/2.S) | | 42041 |
| CHANNEL-2 TUNE (1.A/2.S) | | 42053 |
| CHANNEL-3 TUNE (1.A/2.S) | | 42065 |
| CHANNEL-4 TUNE (1.A/2.S) | | 42077 |

**PID Minimum Set Value Parameters
Modbus Addresses**

| Parameter | | Address |
|-----------------------|-----|---------|
| CHANNEL-1 SET MINIMUM | (*) | 42035 |
| CHANNEL-2 SET MINIMUM | (*) | 42047 |
| CHANNEL-3 SET MINIMUM | (*) | 42059 |
| CHANNEL-4 SET MINIMUM | (*) | 42071 |

**PID Soft Start Parameters
Modbus Addresses**

| Parametre | | Address |
|----------------------|--|---------|
| CHANNEL-1 SOFT START | | 42039 |
| CHANNEL-2 SOFT START | | 42051 |
| CHANNEL-3 SOFT START | | 42063 |
| CHANNEL-4 SOFT START | | 42075 |

**PID Maximum Set Value Parameters
Modbus Addresses**

| Parameter | | Address |
|-----------------------|-----|---------|
| CHANNEL-1 SET MAXIMUM | (*) | 42036 |
| CHANNEL-2 SET MAXIMUM | (*) | 42048 |
| CHANNEL-3 SET MAXIMUM | (*) | 42060 |
| CHANNEL-4 SET MAXIMUM | (*) | 42072 |

**Alarm Type Selection Parameters
Modbus Addresses**

| Parametre | | Address |
|----------------------|--|---------|
| CHANNEL-1 ALARM TYPE | | 42079 |
| CHANNEL-2 ALARM TYPE | | 42083 |
| CHANNEL-3 ALARM TYPE | | 42087 |
| CHANNEL-4 ALARM TYPE | | 42091 |




(*) These parameters are displayed on LCD screen with point, so that the parameters values are 10 times than the real values for modbus function.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.3. Page-3 Parameters



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|--------------|---|------|--------|-------|---------|---------|
| ALARM HYS. | Alarm Hysteresis Value For Channel-X | °C | -200.0 | 200.0 | 1.0 | - |
| ALARM BAND | Alarm Bandwith For Channel-X | °C | 0.0 | 50.0 | 10.0 | - |
| PV. OFFSET | Process Offset Value For Channel-X | °C | -50.0 | 50.0 | 0.0 | - |
| MODE CONTROL | Device Operating Mode Control Selection | - | 0 | 3 | 0 | 42116 |
| TECH. PASS. | Technician Section Password | - | 0 | 9000 | 0 | 42114 |
| OPER. PASS. | Operation Section Password | - | 0 | 9000 | 0 | 42115 |

ALARM HYS.

Alarm hysteresis value for selected channel is can be adjusted according to this parameter.

ALARM BAND

For selected channel alarm bandwith value for band alarm is can be adjusted according to this parameter.

PV. OFFSET

Process offset value for selected channel is can be adjusted according to this parameter.

MODE CONTROL

Device's operating mode is can be controlled according to this parameter value. If parameter value;

- 0 = Mode selection is disable
- 1 = Mode selection can be made via front panel buttons (ECO or SLEEP buttons)
- 2 = Mode selection can be made via digital inputs (ECO or SLEEP mode control inputs)
- 3 = Mode selection can be made automatically according to the ECO and SLEEP mode pages parameters, which each mode can be activating any time of section for each day of week.

TECH.PASS.

Password for entering to the technician section is defined with this parameter.

If it is 0, technician section accessed without entering password.

OPER. PASS.

Password for entering to the operator section is defined with this parameter.

If it is 0, operator section accessed without entering password.



Channel number is can be seen upper left side of the display and can be selected by pressing the channel selection buttons (1, 2, 3 or 4).



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

Alarm Hysteresis Parameters Modbus Addresses

| Parameter | | Address |
|----------------------|-----|---------|
| CHANNEL-1 ALARM HYS. | (*) | 42080 |
| CHANNEL-2 ALARM HYS. | (*) | 42084 |
| CHANNEL-3 ALARM HYS. | (*) | 42088 |
| CHANNEL-4 ALARM HYS. | (*) | 42092 |

Alarm Bandwith Parameters Modbus Addresses

| Parameter | | Address |
|----------------------|-----|---------|
| CHANNEL-1 ALARM BAND | (*) | 42081 |
| CHANNEL-2 ALARM BAND | (*) | 42085 |
| CHANNEL-3 ALARM BAND | (*) | 42089 |
| CHANNEL-4 ALARM BAND | (*) | 42093 |

Proses Offset Value Parameters Modbus Addresses

| Parameter | | Address |
|----------------------|-----|---------|
| CHANNEL-1 PV. OFFSET | (*) | 42098 |
| CHANNEL-2 PV. OFFSET | (*) | 42099 |
| CHANNEL-3 PV. OFFSET | (*) | 42100 |
| CHANNEL-4 PV. OFFSET | (*) | 42101 |





(*) These parameters are displayed on LCD screen with point, so that the parameters values are 10 times than the real values for modbus function.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.4. Page-4 Parameters



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|--------------------|---------------------|--------|------|------|----------|---------------|
| CHANNEL-1 CH. NAME | Channel-1 Label | String | - | - | SENSOR-1 | 42000 - 42004 |
| CHANNEL-2 CH. NAME | Channel-2 Label | String | - | - | SENSOR-2 | 42005 - 42009 |
| CHANNEL-3 CH. NAME | Channel-3 Label | String | - | - | SENSOR-3 | 42010 - 42014 |
| CHANNEL-4 CH. NAME | Channel-4 Label | String | - | - | SENSOR-4 | 42015 - 42019 |
| CHANNEL-1 I/O | Channel-1 Selection | - | 0 | 2 | 1 | 42102 |
| CHANNEL-2 I/O | Channel-2 Selection | - | 0 | 2 | 1 | 42103 |
| CHANNEL-3 I/O | Channel-3 Selection | - | 0 | 2 | 1 | 42104 |
| CHANNEL-4 I/O | Channel-4 Selection | - | 0 | 2 | 1 | 42105 |

CH. NAME “Channels label definition”

All channels have their own label, is displayed in main operation screen. channel labels is can be adjusted by this parameter. Channel labels are can be adjusted maximum 10 characters.

I/O “PID Operation Type Selection Parameter”


PID operation type is selected by this parameter. If parameter value is selected as a 0 (PID disabled) then, PID is not operate, alarm output is not controlled and analogue value for this channel is not recording on USB file. If parameter value,

- 0 = PID function is disabled
- 1 = Heating PID function is selected
- 2 = Cooling PID function is selected



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.5. Page-5 “ECO MODE” Parameters



Technician Parameter
Page Number

| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|-------------------|-------------------------------|--------|------|-------|---------|---------|
| ECO | Auto ECO MODE ENA/DIS | - | 0 | 1 | 0 | - |
| MODE START HOUR | Auto ECO MODE Starting Hour | hour | 0 | 23 | 0 | - |
| MODE START MINUTE | Auto ECO MODE Starting Minute | minute | 0 | 59 | 0 | - |
| TIME | Auto ECO MODE Time | minute | 1 | 1440 | 1 | - |
| ECO SET DIFF. | ECO MODE Set Difference | °C | 0 | 500.0 | 0 | - |

ECO

If MODE CONTROL parameter value selected as 3 (auto mode control is active) then for selected day of week auto eco mode is enable or disable by this parameter. If parameter value;

0 = auto ECO MODE is disable for selected day of week

1 = auto ECO MODE is enable for selected day of week

MODE START HOUR

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto eco mode is active for selected day of week, then auto eco mode starting hour is determined by this parameter.

MODE START MINUTE

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto eco mode is active for selected day of week, then auto eco mode starting minute is determined by this parameter.

TIME

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto eco mode is active for selected day of week, then ECO MODE activating time value is determined by this parameter.

ECO SET DIFF.

Temperature changing of PID Process set value during time while ECO mode is active is determined by this parameter.



While the device works as long as the ECO MODE, “**ECO**” expression is observed in device working mode section of main operation screens and PID process set value is lowered to ECO SET DIFF parameter’s value.

ECO mode PID process set value is calculated like below.

If PID is selected as a heating, **ECO MODE PROCESS SET = PROCESS SET - ECO SET DIFF.**

If PID is selected as a cooling, **ECO MODE PROCESS SET = PROCESS SET + ECO SET DIFF.**



While the device works as long as the SLEEP MODE, ECO MODE can not be activated.

If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

| Auto ECO Mode Parameters for MONDAY | Address |
|--|----------------|
| (MONDAY) ECO | 42117 |
| (MONDAY) ECO MODE STARTING HOUR | 42118 |
| (MONDAY) ECO MODE STARTING MINUTE | 42119 |
| (MONDAY) ECO MODE TIME | 42120 |
| (MONDAY) ECO MODE SET DIFF. (*) | 42121 |

| Auto ECO Mode Parameters for TUESDAY | Address |
|---|----------------|
| (TUESDAY) ECO | 42126 |
| (TUESDAY) ECO MODE STARTING HOUR | 42127 |
| (TUESDAY) ECO MODE STARTING MINUTE | 42128 |
| (TUESDAY) ECO MODE TIME | 42129 |
| (TUESDAY) ECO MODE SET DIFF. (*) | 42130 |

| Auto ECO Mode Parameters for WEDNESDAY | Address |
|---|----------------|
| (WEDNESDAY) ECO | 42135 |
| (WEDNESDAY) ECO MODE STARTING HOUR | 42136 |
| (WEDNESDAY) ECO MODE STARTING MINUTE | 42137 |
| (WEDNESDAY) ECO MODE TIME | 42138 |
| (WEDNESDAY) ECO MODE SET DIFF. (*) | 42139 |

| Auto ECO Mode Parameters for THURSDAY | Address |
|--|----------------|
| (THURSDAY) ECO | 42144 |
| (THURSDAY) ECO MODE STARTING HOUR | 42145 |
| (THURSDAY) ECO MODE STARTING MINUTE | 42146 |
| (THURSDAY) ECO MODE TIME | 42147 |
| (THURSDAY) ECO MODE SET DIFF. (*) | 42148 |

| Auto ECO Mode Parameters for FRIDAY | Address |
|--|----------------|
| (FRIDAY) ECO | 42153 |
| (FRIDAY) ECO MODE STARTING HOUR | 42154 |
| (FRIDAY) ECO MODE STARTING MINUTE | 42155 |
| (FRIDAY) ECO MODE TIME | 42156 |
| (FRIDAY) ECO MODE SET DIFF. (*) | 42157 |

| Auto ECO Mode Parameters for SATURDAY | Address |
|--|----------------|
| (SATURDAY) ECO | 42162 |
| (SATURDAY) ECO MODE STARTING HOUR | 42163 |
| (SATURDAY) ECO MODE STARTING MINUTE | 42164 |
| (SATURDAY) ECO MODE TIME | 42165 |
| (SATURDAY) ECO MODE SET DIFF. (*) | 42166 |

| Auto ECO Mode Parameters for SUNDAY | Address |
|--|----------------|
| (SUNDAY) ECO | 42171 |
| (SUNDAY) ECO MODE STARTING HOUR | 42172 |
| (SUNDAY) ECO MODE STARTING MINUTE | 42173 |
| (SUNDAY) ECO MODE TIME | 42174 |
| (SUNDAY) ECO MODE SET DIFF. (*) | 42175 |



(*) These parameters are displayed on LCD screen with point, so that the parameters values are 10 times than the real values for modbus function.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.6. Page-6 “SLEEP MODE” Parameters



Technician Parameter
Page Number

| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|-------------------|---------------------------------|--------|------|------|---------|---------|
| SLEEP | Auto SLEEP MODE ENA/DIS | - | 0 | 1 | 0 | - |
| MODE START HOUR | Auto SLEEP MODE Starting Hour | hour | 0 | 23 | 0 | - |
| MODE START MINUTE | Auto SLEEP MODE Starting Minute | minute | 0 | 59 | 0 | - |
| TIME | Auto SLEEP MODE Time | minute | 1 | 1440 | 1 | - |

SLEEP

If MODE CONTROL parameter value selected as 3 (auto mode control is active) then for selected day of week auto sleep mode is enable or disable by this parameter. If parameter value;

0 = auto SLEEP MODE is disable for selected day of week

1 = auto SLEEP MODE is enable for selected day of week

MODE START HOUR

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto sleep mode is active for selected day of week, then auto sleep mode starting hour is determined by this parameter.

MODE START MINUTE

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto sleep mode is active for selected day of week, then auto sleep mode starting minute is determined by this parameter.

TIME

If MODE CONTROL parameter value selected as 3 (auto mode control is active) and auto sleep mode is active for selected day of week, then SLEEP MODE activating time value is determined by this parameter.



While the device works as long as the SLEEP MODE, “**SLEEP**” expression is observed in device working mode section of main operation screens and PID Outputs are closed.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

| Auto SLEEP Mode Parameters for MONDAY | Address |
|--|----------------|
| (MONDAY) SLEEP | 42122 |
| (MONDAY) SLEEP MODE STARTING HOUR | 42123 |
| (MONDAY) SLEEP MODE STARTING MINUTE | 42124 |
| (MONDAY) SLEEP MODE TIME | 42125 |

| Auto SLEEP Mode Parameters for TUESDAY | Address |
|---|----------------|
| (TUESDAY) SLEEP | 42131 |
| (TUESDAY) SLEEP MODE STARTING HOUR | 42132 |
| (TUESDAY) SLEEP MODE STARTING MINUTE | 42133 |
| (TUESDAY) SLEEP MODE TIME | 42134 |

| Auto SLEEP Mode Parameters for WEDNESDAY | Address |
|---|----------------|
| (WEDNESDAY) SLEEP | 42140 |
| (WEDNESDAY) SLEEP MODE STARTING HOUR | 42141 |
| (WEDNESDAY) SLEEP MODE STARTING MINUTE | 42142 |
| (WEDNESDAY) SLEEP MODE TIME | 42143 |

| Auto SLEEP Mode Parameters for THURSDAY | Address |
|--|----------------|
| (THURSDAY) SLEEP | 42149 |
| (THURSDAY) SLEEP MODE STARTING HOUR | 42150 |
| (THURSDAY) SLEEP MODE STARTING MINUTE | 42151 |
| (THURSDAY) SLEEP MODE TIME | 42152 |

| Auto SLEEP Mode Parameters for FRIDAY | Address |
|--|----------------|
| (FRIDAY) SLEEP | 42158 |
| (FRIDAY) SLEEP MODE STARTING HOUR | 42159 |
| (FRIDAY) SLEEP MODE STARTING MINUTE | 42160 |
| (FRIDAY) SLEEP MODE TIME | 42161 |

| Auto SLEEP Mode Parameters for SATURDAY | Address |
|--|----------------|
| (SATURDAY) SLEEP | 42167 |
| (SATURDAY) SLEEP MODE STARTING HOUR | 42168 |
| (SATURDAY) SLEEP MODE STARTING MINUTE | 42169 |
| (SATURDAY) SLEEP MODE TIME | 42170 |

| Auto SLEEP Mode Parameters for SUNDAY | Address |
|--|----------------|
| (SUNDAY) SLEEP | 42176 |
| (SUNDAY) SLEEP MODE STARTING HOUR | 42177 |
| (SUNDAY) SLEEP MODE STARTING MINUTE | 42178 |
| (SUNDAY) SLEEP MODE TIME | 42179 |



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.7. Page-7 “RS232” Parameters



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|-----------|----------------------------------|------|------|------|---------|---------|
| BAUDRATE | Baudrate For RS232 Communication | - | 1 | 6 | 6 | 42106 |
| PARITY | Parity For RS232 Communication | - | 0 | 2 | 0 | 42107 |
| STOP BIT | Stop Bit For RS232 Communication | - | 1 | 2 | 1 | 42108 |
| ID | ID For RS232 Communication | - | 1 | 247 | 1 | 42109 |

BAUDRATE

Modbus communication baudrate for RS232 is can be adjusted by this parameter. If parameter value,

- 1 = 4800
- 2 = 9600
- 3 = 19200
- 4 = 38400
- 5 = 57600
- 6 = 115200

PARITY

Modbus communication parity bit for RS232 is can be adjusted by this parameter. If parameter value,

- 0 = No Parity
- 1 = ODD Parity
- 2 = EVEN Parity

STOP BIT

Modbus communication stop bit for RS232 is can be adjusted by this parameter. If parameter value,

- 1 = 1 Stop bit
- 2 = 2 Stop bits

ID

Modbus communication device ID for RS232 is can be adjusted by this parameter. This parameter value is can be adjusted from 1 to 247 (except 85 and 170).



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|-----------|----------------------------------|------|------|------|---------|---------|
| BAUDRATE | Baudrate For RS485 Communication | - | 1 | 6 | 2 | 42110 |
| PARITY | Parity For RS485 Communication | - | 0 | 2 | 0 | 42111 |
| STOP BIT | Stop Bit For RS485 Communication | - | 1 | 2 | 1 | 42112 |
| ID | ID For RS485 Communication | - | 1 | 247 | 1 | 42113 |

BAUDRATE

Modbus communication baudrate for RS485 is can be adjusted by this parameter. If parameter value,

- 1 = 4800
- 2 = 9600
- 3 = 19200
- 4 = 38400
- 5 = 57600
- 6 = 115200

PARITY

Modbus communication parity bit for RS485 is can be adjusted by this parameter. If parameter value,

- 0 = No Parity
- 1 = ODD Parity
- 2 = EVEN Parity

STOP BIT

Modbus communication stop bit for RS485 is can be adjusted by this parameter. If parameter value,

- 1 = 1 Stop bit
- 2 = 2 Stop bits

ID


Modbus communication device ID for RS485 is can be adjusted by this parameter.



If the device has a optional RS485 communication then RS 485 page is observed, Otherwise these page is not observed.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.



| Parameter | Explanation | Unit | Min | Max | Default | Address |
|------------|--------------------------|--------|-----|------|----------|---------------|
| FILE NAME | USB File Name | String | - | - | QUAD.txt | 42020 - 42024 |
| LABEL | USB Label | String | - | - | SAMPLE | 42025 - 42029 |
| SAVE TIME | USB Time Record ENA/DIS | - | 0 | 1 | 1 | 42180 |
| SAMP. TIME | USB Record Time Interval | Sec. | 0 | 3600 | 1 | 42181 |

FILE NAME

USB file name for recording analogue values is can be adjusted by this parameter. File name can be adjusted maximum 10 characters. Recording file on usb is “csv” format and all data is separated each other with tab. Example file format is explained below.

LABEL

When the analogue values are recorded on USB file, user can be defined label for this recording. Label can be adjusted maximum 10 characters. Label are recorded at the end of every lines of file.

SAVE TIME

When the analogue values are recorded on USB file, user can be save the recording time on the file. Recording time is recorded at the beginning of every lines of file.

- 0 = Real time is not recorded on USB file
- 1 = Real time is recorded on USB file for every sample

SAMPLE TIME

Record time interval is can be adjusted by this parameter. Analogue values are recorded on USB file with this time interval. If this parameter value is 0 usb recording is disabled.

FLASH MEM. PLUGGED “USB Flash Memory Stick Detected Test”

When the usb flash memory stick is plugged to the device FLASH MEM.PLUGGED led is light on. This parameter is can not be changed, it’s used to inform the user whether USB is plugged.

USB Recording File Example


| | | | | | |
|---------------------|-----------------|-----------------|-----------------|-----------------|--------|
| 2011-08-03-17:26:09 | 35.2 | 35.2 | 29.7 | 31.8 | SAMPLE |
| 2011-08-03-17:26:10 | 35.2 | 35.2 | 29.7 | 31.8 | SAMPLE |
| 2011-08-03-17:26:12 | 35.2 | 35.2 | 29.7 | 31.8 | SAMPLE |
| 2011-08-03-17:26:13 | 35.2 | 35.2 | 29.7 | 31.8 | SAMPLE |
| Recording Time | CHANNEL-1 Value | CHANNEL-2 Value | CHANNEL-3 Value | CHANNEL-4 Value | Label |



If the device has a optional USB communication then USB page is observed. Otherwise these page is not observed.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.



| Parameter | Explanation | Unit | Min. | Max. | Default | Address |
|------------------|---------------------------|---------|------|-------|---------------|---------------|
| DHCP | DHCP Enable /Disable (**) | ENA/DIS | 0 | 1 | 0 | 42209 |
| ETH. PORT | ETHERNET Port No (**) | - | 1 | 65535 | 502 | 42210 |
| ETH. IP NO | Ethernet IP No (**) | - | - | - | 192.168.0.250 | 42211 - 42212 |
| ETH. NETMASK | Ethernet Netmask (**) | - | - | - | 255.255.255.0 | 42213 - 42214 |
| ETH. GATEWAY | Ethernet Gateway (**) | - | - | - | 192.168.0.1 | 42215 - 42216 |
| ETH. TCP/IP SLCT | TCP/IP Select (**) | - | 0 | 1 | 0 | - |
| DEVICE MAC ADR. | Device MAC Address (**) | - | - | - | - | 42217 - 42219 |

DHCP

DHCP is an automatic configuration protocol used on IP networks, If DHCP is enable, device is adjust our ethernet communication configuration parameters (IP, Netmask,Gateway) dynamicaly for your network system. If DHCP is disable, you must adjust ethernet configuration parameters (IP, Netmask,Gateway) for your network system. If parameter value,

- 0 = DHCP DISABLE
- 1 = DHCP ENABLE

ETH.PORT

Ethernet port number is can be adjusted by this parameter.

NET MASK

Subnet mask for ethernet communication is can be adjusted by this parameter. If DHCP is selected as a enable there is no need to adjust to this parameter, if DHCP is selected as a disable then user must adjust this parameter according to the their own network system.

GATEWAY

Gateway for ethernet communication is can be adjusted by this parameter. If DHCP is selected as a enable there is no need to adjust to this parameter, if DHCP is selected as a disable then user must adjust this parameter according to the their own network system.

IP

IP address for ethernet communication is can be adjusted by this parameter. If DHCP is selected as a enable there is no need to adjust to this parameter, if DHCP is selected as a disable then user must adjust this parameter.

PORT SET

Ethernet port configuration is setting by this parameter, After the all parameter adjusted according to system needs, this parameter value is must be adjusted to 1 for ethernet port setting, after ethernet port setting is completed this parameter value is turn to zero automatically.

TCP/IP SLCT

TCP/IP protocol is selected by this parameter. **0 = Modbus RTU Over TCP/IP 1 = Modbus RTU TCP/IP**



(**) These parameters are only read for modbus function.



If the device has a optional ETHERNET communication then ETHERNET pages is observed. Otherwise these pages are not observed.



If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

6.7.11. Page-11 “REAL TIME (RTC)” Parameters



Press and hold on 3 seconds Enter button for setting the RTC time value.

| Parameter | Explanation | Unit | Min | Max | Default |
|-----------|---------------------------|------|------|------|---------|
| YEAR | Year Value For RTC Time | - | 2010 | 3000 | - |
| MONTH | Month Value For RTC Time | - | 1 | 12 | - |
| DAY | Day Value For RTC Time | - | 1 | 31 | - |
| HOUR | Hour Value For RTC Time | - | 0 | 23 | - |
| MINUTE | Minute Value For RTC Time | - | 0 | 59 | - |
| SECOND | Second Value For RTC Time | - | 0 | 59 | - |

YEAR

Year value for RTC time is adjusted by this parameter.

MONTH

Month value for RTC time is adjusted by this parameter.

DAY

Day value for RTC time is adjusted by this parameter.

HOUR

Hour value for RTC time is adjusted by this parameter.

MINUTE

Minute value for RTC time is adjusted by this parameter.

SECOND


Second value for RTC time is adjusted by this parameter.




If no operation is performed for 20 seconds in technician parameters section, device turns to main operation screen automatically.

7. Operation Graphics of Alarm Types


High Alarm



Low Alarm



Band Alarm



SET = Alarm Set value
HYS = Hysteresis value for Alarm output
BAND = Bandwidth for Band Alarm

8. Modbus Addresses

8.1. PID Control and Alarm Output Modbus Addresses

| OUTPUTS | | Unit | Address |
|---------------------------|-------------------------------------|------|---------|
| CHANNEL-1 PID CONTROL OUT | Channel-1 PID Control Output Status | - | 00001 |
| CHANNEL-2 PID CONTROL OUT | Channel-2 PID Control Output Status | - | 00002 |
| CHANNEL-3 PID CONTROL OUT | Channel-3 PID Control Output Status | - | 00003 |
| CHANNEL-4 PID CONTROL OUT | Channel-4 PID Control Output Status | - | 00004 |
| - | - | - | 00005 |
| CHANNEL-1 ALARM OUT | Channel-1 Alarm Output Status | - | 00006 |
| CHANNEL-2 ALARM OUT | Channel-2 Alarm Output Status | - | 00007 |
| CHANNEL-3 ALARM OUT | Channel-3 Alarm Output Status | - | 00008 |
| CHANNEL-4 ALARM OUT | Channel-4 Alarm Output Status | - | 00009 |
| GENERAL ALARM OUT | General Alarm Output Status | - | 00010 |

Note-1: Outputs status are can be readed with modbus function-1 (read coils). Device's response for modbus function-1 is always 2 byte data although the modbus function request less than 9 outputs port.

8.2. Process Input Values Modbus Addresses

| PROCESS INPUTS | | Unit | Address |
|-------------------------|-------------------------|------|---------|
| CHANNEL-1 PROCESS VALUE | Channel-1 Process Value | °C | 30001 |
| CHANNEL-2 PROCESS VALUE | Channel-2 Process Value | °C | 30002 |
| CHANNEL-3 PROCESS VALUE | Channel-3 Process Value | °C | 30003 |
| CHANNEL-4 PROCESS VALUE | Channel-4 Process Value | °C | 30004 |

Note-2: Process Input values can be readed with modbus function-4 (read input register). Because of the process values are displayed on LCD screen with point, the reading values from modbus will be 10 times more than the real values.

9. Specifications

| | |
|---|--|
| Device Type | : 4 Channel PID Controller |
| Housing & Mounting | : 96mm x 96mm x 87.5mm 1/4 DIN 43700 plastic housing for panel mounting. Panel cut-out is 92 x 92mm. |
| Protection Class | : NEMA 4X (IP65 at front, IP20 at rear) |
| Weight | : Approximately 0.4Kg. |
| Environmental Ratings with none | : Standard, indoor at an altitude of less than 2000 meters condensing humidity |
| Storage / Operating Temperature: | : -20 °C to +70 °C / 0 °C to +50 °C |
| Storage / Operating Humidity | : 90 % max. (None condensing) |
| Installation | : Fixed installation |
| Overvoltage Category | : II |
| Pollution Degree | : II. office or workplace, none conductive pollution |
| Operating Conditions | : Continuous |
| Device Supply Voltage and Power | : 100 - 240 V ~ (-%15 / +%10) 50/60 Hz. 7VA 24 V ~ (-%15 / +%10) 50/60 Hz. 7VA 24 V = (-%15 / +%10) 7W |
| Analogue Inputs | : Thermocouple J,K,R,S (IEC584.1)(ITS90), L (DIN43710) |
| Accuracy | : ± 0,25% of full scale |
| Line Compensation | : Maximum 10 |
| Sensor Break Protection | : Upscale |
| Sampling Time | : 1400msecs. |
| Input Resistance | : > 10M |
| Control Forms | : Programmable P, PI, PD or PID. |
| Relay Output | : Resistive Load 5A@250V~ (Electrical Life : 100.000 operation (Full Load)) |
| Standard Communication | : RS-232 Communication (For Modbus RTU) |
| Optional Communication | : RS-485 (For Modbus RTU) "500V~ isolated" 10Mbits/s Ethernet (For Modbus RTU Over TCP - Modbus RTU TCP/IP selectable) "1500V~ isolated" USB 2.0 (Data logging over Flash Stick Memory) |
| Display | : 128 x 64 pixel graphical LCD |
| Approvals | : GOST-R, CE |

10. Other Informations

Manufacturer Information:

Emko Elektronik Sanayi ve Ticaret A.Ş.

Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369

BURSA/TURKEY Phone : +90 224 261 1900 Fax : +90 224 261 1912

Repair and Maintenance Service Information:

Emko Elektronik Sanayi ve Ticaret A.Ş.

Demirtaş Organize Sanayi Bölgesi Karanfil Sk. No:6 16369

BURSA/TURKEY Phone : +90 224 261 1900 Fax : +90 224 261 1912



Your Technology Partner

Thank you very much for your preference to use Emko Elektronik

Products.

www.emkoelektronik.com.tr